

2321-0012
MEMPHIS FATS MOUNTING KIT, KAWASAKI VN2000-A1 CC '04
INSTRUCTION SHEET/PARTS LIST

TOOLS REQUIRED: 5mm Allen wrench (provided)
6mm Allen wrench (provided)

3/16" Allen wrench (provided)
7/16" or 11 mm Wrench

ALWAYS COVER THE FRONT FENDER AND GAS TANK TO AVOID POSSIBLE DAMAGE

1. Loosely attach the windshield mounting plates to the windshield, using the bottom bolt and the third bolt up. The small tab goes at the bottom, big tab at the top. The tabs on the mounting plates point in towards each other when installed correctly.
2. Locate the original upper and lower mounting points on the sides of the front fork covers.
3. Remove the original bolts located on the sides of the covers. Loosely install the new top and bottom spacers and mounting bolts provided.
4. Install the windshield by slipping the windshield mounting plates, bottom first, onto the mounting bolts. Adjust the height and angle of the windshield and tighten all mounting bolts.

WARNING: NEVER RIDE WITH ANY PART OF YOUR MOUNTING HARDWARE MISSING OR LOOSE

Care and Cleaning Instructions

To clean your windshield, use only warm water and a mild non-abrasive, dishwashing liquid. Use a soft cloth, such as a T-shirt or flannel cloth. To protect your windshield, please use Novus #2 to remove minor scratches, or use a polish like Memphis Shades Shinola which is specially designed for plastic windshields; glass cleansing agents will cause severe damage to your windshield and will void your warranty.

Never use any glass products, petroleum based chemicals, or cleaning agents with ammonia, bleach or any harsh chemicals. This includes Rain-X, brake fluid, acetone, and gasoline.

**2321-0012 MOUNTING KIT
MEMPHIS FATS KAWASAKI VN2000-A1 CC '04**

PART #	DESCRIPTION	QTY.
M983	Mounting Instructions/Parts List	1
M1057	Left Mounting Plate Fats	1
M1058	Right Mounting Plate Fats	1
M309	8mm x 20mm SS Socket Head Cap Screw	4
R567	7/8" Beveled Socket Washer	4
R502	7/8" Spacer Washer, Thin	4
M310	3/16" Short Arm Allen Wrench	1
M313	3/16" Short Arm Allen Wrench Cover	1
R303	5mm Short Arm Allen Wrench	1
M311	6mm Short Arm Allen Wrench	1

**Memphis Shades warrants all product components, metal and plastic,
against defects in materials and workmanship for 24 months.**

FOR PARTS AND WARRANTY HELP, CONTACT:

MEMPHIS SHADES

P.O. Box 429

Rossville, TN 38066

(901) 853-0293

Visit us on the web at www.memphisshades.com or

you can also reach us at

customerservice@memphisshades.com